



Sizing Table - Inches

Item#	Width Cushion	Width Chair	Depth Cushion	Depth Chair	Item#	Width Cushion	Width Chair	Depth Cushion	Depth Chair
1R77M-CA-SR 1R77M-CH-SR	13 1/4	11 3/4 - 13 1/4	13 1/4	11 3/4 - 13 1/4	1R109M-CA-SR 1R109M-CH-SR	18 1/4	16 3/4 - 18 1/2	16 1/2	15 - 16 3/4
1R78M-CA-SR 1R78M-CH-SR	13 1/4	11 3/4 - 13 1/4	14 3/4	13 1/4 - 15	1R1010M-CA-SR 1R1010M-CH-SR	18 1/4	16 3/4 - 18 1/2	18 1/4	16 3/4 - 18 1/2
1R88M-CA-SR 1R88M-CH-SR	14 3/4	13 1/4 - 15	14 3/4	13 1/4 - 15	1R1011M-CA-SR 1R1011M-CH-SR	18 1/4	16 3/4 - 18 1/2	20	18 1/2 - 20 1/4
1R89M-CA-SR 1R89M-CH-SR	14 3/4	13 1/4 - 15	16 1/2	15 - 16 3/4	1R1110M-CA-SR 1R1110M-CH-SR	20	18 1/2 - 20 1/4	18 1/4	16 3/4 - 18 1/2
1R99M-CA-SR 1R99M-CH-SR	16 1/2	15 - 16 3/4	16 1/2	15 - 16 3/4	1R1111M-CA-SR 1R1111M-CH-SR	20	18 1/2 - 20 1/4	20	18 1/2 - 20 1/4
1R910M-CA-SR 1R910M-CH-SR	16 1/2	15 - 16 3/4	18 1/4	16 3/4 - 18 1/2					

Sizing Table - CM

Item#	Width Cushion	Width Chair	Depth Cushion	Depth Chair	Item#	Width Cushion	Width Chair	Depth Cushion	Depth Chair
1R77M-CA-SR 1R77M-CH-SR	33,5	29,5 - 34	33,5	29,5 - 34	1R109M-CA-SR 1R109M-CH-SR	46,5	42,5 - 47	42	38 - 42,5
1R78M-CA-SR 1R78M-CH-SR	33,5	29,5 - 34	37,5	34 - 38	1R1010M-CA-SR 1R1010M-CH-SR	46,5	42,5 - 47	46,5	42,5 - 47
1R88M-CA-SR 1R88M-CH-SR	37,5	34 - 38	37,5	34 - 38	1R1011M-CA-SR 1R1011M-CH-SR	46,5	42,5 - 47	50,5	47 - 51
1R89M-CA-SR 1R89M-CH-SR	37,5	34 - 38	42	38 - 42,5	1R1110M-CA-SR 1R1110M-CH-SR	50,5	47 - 51	46,5	42,5 - 47
1R99M-CA-SR 1R99M-CH-SR	42	38 - 42,5	42	38 - 42,5	1R1111M-CA-SR 1R1111M-CH-SR	50,5	47 - 51	50,5	47 - 51
1R910M-CA-SR 1R910M-CH-SR	42	38 - 42,5	46,5	42,5 - 47					

CA: Represents the Standard Cover option
 CH: Represents the Heavy Duty Cover option